



ROV MOSFET SWITCH

INSTALLATION MANUAL

Enhance your BlueROV2 with iSENSYS Mosfet battery switch, easily mountable on the 3' battery tube flange. This upgrade introduces an external switch, eliminating the need to open the battery compartment and reducing moisture risk. It enables preflight setups and conserves battery life, extending mission duration.



